



$\Delta\sigma/\sigma$  vs. E for  $^{27}\text{Al}(n,\text{tot.})$



Ordinate scales are % relative standard deviation and barns.

Abscissa scales are energy (eV).


$\sigma$  vs. E for  $^{27}\text{Al}(n,\text{tot.})$



Correlation Matrix




$\Delta\sigma/\sigma$  vs. E for  $^{27}\text{Al}(n,\text{el.})$



Ordinate scales are % relative standard deviation and barns.

Abscissa scales are energy (eV).


$\sigma$  vs. E for  $^{27}\text{Al}(n,\text{el.})$



Correlation Matrix




### $\Delta\sigma/\sigma$ vs. E for $^{27}\text{Al}(\text{n},\text{inel.})$





Ordinate scales are % relative standard deviation and barns.

Abscissa scales are energy (eV).


### $\sigma$ vs. E for $^{27}\text{Al}(\text{n},\text{inel.})$



Correlation Matrix




$\Delta\sigma/\sigma$  vs. E for  $^{27}\text{Al}(n,2n)$



Ordinate scales are % relative standard deviation and barns.


Abscissa scales are energy (eV).

$\sigma$  vs. E for  $^{27}\text{Al}(n,2n)$





Correlation Matrix





Ordinate scales are % relative standard deviation and barns.

Abscissa scales are energy (eV).



Correlation Matrix

