




$\Delta v/v$ vs. E for $^{227}\text{Ac}(\text{total } \nu)$




Ordinate scales are % relative standard deviation and nu-bar.


Abscissa scales are energy (eV).



Correlation Matrix




$\Delta\nu/\nu$ vs. E for $^{227}\text{Ac}(\text{delayed } \nu)$




Ordinate scales are % relative standard deviation and nu-bar.

Abscissa scales are energy (eV).




Correlation Matrix




$\bar{\nu}$ vs. E for $^{227}\text{Ac}(\text{delayed } \nu)$

$\Delta v/v$ vs. E for $^{227}\text{Ac}(\text{prompt } \nu)$




Ordinate scales are % relative standard deviation and nu-bar.

Abscissa scales are energy (eV).




Correlation Matrix




$\bar{\nu}$ vs. E for $^{227}\text{Ac}(\text{prompt } \nu)$

$\Delta\sigma/\sigma$ vs. E for $^{227}\text{Ac}(n,\text{tot.})$





Ordinate scales are % relative standard deviation and barns.

Abscissa scales are energy (eV).




Correlation Matrix




σ vs. E for $^{227}\text{Ac}(n,\text{tot.})$

$\Delta\sigma/\sigma$ vs. E for $^{227}\text{Ac}(n,\text{el.})$





Ordinate scales are % relative standard deviation and barns.

Abscissa scales are energy (eV).




Correlation Matrix




σ vs. E for $^{227}\text{Ac}(n,\text{el.})$

$\Delta\sigma/\sigma$ vs. E for $^{227}\text{Ac}(n,\text{inel.})$




Ordinate scales are % relative standard deviation and barns.


Abscissa scales are energy (eV).



Correlation Matrix




$\Delta\sigma/\sigma$ vs. E for $^{227}\text{Ac}(n,2n)$




Ordinate scales are % relative standard deviation and barns.

Abscissa scales are energy (eV).




Correlation Matrix



σ vs. E for $^{227}\text{Ac}(n,2n)$

$\Delta\sigma/\sigma$ vs. E for $^{227}\text{Ac}(n,f)$




Ordinate scales are % relative standard deviation and barns.


Abscissa scales are energy (eV).



Correlation Matrix




$\Delta\sigma/\sigma$ vs. E for $^{227}\text{Ac}(n,\gamma)$





Ordinate scales are % relative standard deviation and barns.

Abscissa scales are energy (eV).





Correlation Matrix





σ vs. E for $^{227}\text{Ac}(n,\gamma)$


$\Delta\mu/\mu$ vs. E for $^{227}\text{Ac}(\text{mt251})$




Correlation Matrix





$\Delta\phi/\phi$ vs. E for $^{227}\text{Ac}(n,f)$



Ordinate scales are % standard deviation and spectrum/eV.
 Abscissa scales are energy (eV).
 Warning: some uncertainty data were suppressed.



Correlation Matrix



Grp-average $\phi(E_{in} = 2.00 \text{ MeV})$, $^{227}\text{Ac}(n,f)$