




$\Delta\sigma/\sigma$ vs. E for $^{47}\text{Ti}(n,\text{tot.})$






Ordinate scales are % relative standard deviation and barns.

Abscissa scales are energy (eV).




Correlation Matrix








Ordinate scales are % relative standard deviation and barns.


Abscissa scales are energy (eV).



Correlation Matrix




$\Delta\sigma/\sigma$ vs. E for $^{47}\text{Ti}(n,\text{inel.})$




Ordinate scales are % relative
standard deviation and barns.

Abscissa scales are energy (eV).


σ vs. E for $^{47}\text{Ti}(n,\text{inel.})$



Correlation Matrix




$\Delta\sigma/\sigma$ vs. E for $^{47}\text{Ti}(n,2n)$



Ordinate scales are % relative standard deviation and barns.

Abscissa scales are energy (eV).


σ vs. E for $^{47}\text{Ti}(n,2n)$



Correlation Matrix




$\Delta\sigma/\sigma$ vs. E for $^{47}\text{Ti}(n,\gamma)$



Ordinate scales are % relative standard deviation and barns.

Abscissa scales are energy (eV).

σ vs. E for $^{47}\text{Ti}(n,\gamma)$



Correlation Matrix

