



$\Delta\sigma/\sigma$ vs. E for $^{49}\text{Ti}(n,\text{tot.})$




Ordinate scales are % relative standard deviation and barns.

Abscissa scales are energy (eV).


σ vs. E for $^{49}\text{Ti}(n,\text{tot.})$



Correlation Matrix




$\Delta\sigma/\sigma$ vs. E for $^{49}\text{Ti}(n,\text{el.})$





Ordinate scales are % relative standard deviation and barns.

Abscissa scales are energy (eV).


σ vs. E for $^{49}\text{Ti}(n,\text{el.})$



Correlation Matrix




$\Delta\sigma/\sigma$ vs. E for $^{49}\text{Ti}(n,\text{inel.})$






Ordinate scales are % relative standard deviation and barns.

Abscissa scales are energy (eV).




Correlation Matrix



σ vs. E for $^{49}\text{Ti}(n,\text{inel.})$


$\Delta\sigma/\sigma$ vs. E for $^{49}\text{Ti}(n,\gamma)$



Ordinate scales are % relative standard deviation and barns.

Abscissa scales are energy (eV).

σ vs. E for $^{49}\text{Ti}(n,\gamma)$



Correlation Matrix

