



$\Delta\sigma/\sigma$  vs. E for  $^{50}\text{Ti}(n,\text{tot.})$




Ordinate scales are % relative standard deviation and barns.


Abscissa scales are energy (eV).

$\sigma$  vs. E for  $^{50}\text{Ti}(n,\text{tot.})$





Correlation Matrix






Ordinate scales are % relative standard deviation and barns.


Abscissa scales are energy (eV).



Correlation Matrix





$\Delta\sigma/\sigma$  vs. E for  $^{50}\text{Ti}(n,\text{inel.})$





Ordinate scales are % relative standard deviation and barns.


Abscissa scales are energy (eV).



Correlation Matrix




### $\Delta\sigma/\sigma$ vs. E for $^{50}\text{Ti}(n,2n)$



Ordinate scales are % relative standard deviation and barns.


Abscissa scales are energy (eV).

### $\sigma$ vs. E for $^{50}\text{Ti}(n,2n)$



Correlation Matrix





Ordinate scales are % relative standard deviation and barns.

Abscissa scales are energy (eV).

