



$\Delta\sigma/\sigma$  vs. E for  $^{106}\text{Ru}(n,\text{el.})$






Ordinate scales are % relative standard deviation and barns.


Abscissa scales are energy (eV).



Correlation Matrix




$\Delta\sigma/\sigma$  vs. E for  $^{106}\text{Ru}(n,\text{inel.})$




Ordinate scales are % relative standard deviation and barns.

Abscissa scales are energy (eV).


$\sigma$  vs. E for  $^{106}\text{Ru}(n,\text{inel.})$



Correlation Matrix




$\Delta\sigma/\sigma$  vs. E for  $^{106}\text{Ru}(n,2n)$



Ordinate scales are % relative  
standard deviation and barns.

Abscissa scales are energy (eV).


$\sigma$  vs. E for  $^{106}\text{Ru}(n,2n)$



Correlation Matrix




### $\Delta\sigma/\sigma$ vs. E for $^{106}\text{Ru}(n,\gamma)$



Ordinate scales are % relative standard deviation and barns.

Abscissa scales are energy (eV).

### $\sigma$ vs. E for $^{106}\text{Ru}(n,\gamma)$



Correlation Matrix

